

CSE KTM690 Brake Pedal – 2011 and up

Installing the Brake Pedal

1. Remove the entire foot rest bracket from the bike.
2. Remove the return spring and push rod.
3. Remove the OEM brake lever.
4. Apply Loctite to the pivot bolt threads and torque to the factory specification .
5. Check for free movement of the pedal before reattaching the return spring. If the pedal doesn't move freely, remove it and check for any high spots in the foot rest bracket around the pivot hole. We have relieved the brake pedal to clear this area, but there may be imperfections in the factory casting.
6. Attach the return spring and push rod.
7. Reattach foot rest bracket to the motorcycle following the factory recommendations.
8. Once everything is together make sure that the rear brake line is routed correctly and not interfering with the brake pedal mechanism.

Clean Speed Engineering (CSE) LLC is not responsible for any issues resulting from the use of our products.