

3-2-17

Clean Speed KTM 1190/1290 Brake Pedal

Installing the Brake Pedal

1. Remove the OEM brake pedal by removing the master cylinder rod, pivot bolt/nut and return spring.
2. Install the Clean Speed brake pedal by starting it in with the tip pointing towards the ground and rotating it up as the return spring boss clears the engine case.
3. We have a video on our website that shows pedal installation – www.cleanspeedeng.com
4. Once the pedal is in place hook up the return spring.
5. Insert the pivot bolt.
6. Apply Loctite or other thread locker to the pivot bolt nut and torque to KTM factory specification.
7. Apply Loctite or other thread locker to the master cylinder push rod bolt and torque to KTM factory specification.
8. With the bike on the center stand or appropriate lift, check for free movement of the pedal and no interference, KTM factory specification for the amount of freeplay, no rear wheel drag when brake pedal is not applied and appropriate stopping power when rear brake pedal is depressed.

Clean Speed Engineering (CSE) LLC is not responsible for any issues resulting from the use of our products.