

1-3-18

Clean Speed KTM 950/990 Rear Brake Pedal

Installing the Brake Pedal

1. Remove the OEM brake pedal by removing the master cylinder rod, pivot bolt/nut and return spring.
2. Install the Clean Speed brake pedal by attaching the return spring and inserting the pivot bolt and nut.
3. Apply Loctite or other thread locker to the pivot bolt nut and torque to KTM factory specification.
4. Insert the pin that connects the master cylinder push rod to the brake pedal arm. Install washer and new retention clip. Double check that retention clip is locked in place.
5. With the bike on the center stand or appropriate lift, check for free movement of the pedal and no interference, KTM factory specification for the amount of freeplay, no rear wheel drag when brake pedal is not applied and appropriate stopping power when rear brake pedal is depressed.

Clean Speed Engineering (CSE) LLC is not responsible for any issues resulting from the use of our products.