

CSE Scotts Submount Cable Guide Instructions

Installing the Cable Guide

1. Remove two screws from the top of your damper. See the picture below.
2. Drop one of the provided stainless spacers in each counterbore in the damper.
3. Spread the Cable Guide apart at the interlocking joint and slide it around the cables, lines, etc..
4. Lock the Cable Guide back together and screw it down to the damper using the included hex wrench.

BE CAREFUL WHEN TIGHTENING THE CABLE GUIDE SCREWS - THESE ARE SMALL THREADS IN ALUMINUM - DO NOT OVERTIGHTEN.

5. Once you have the Cable Guide mounted where you like it, be sure to put the bike on a stand and turn the bars from stop to stop to make sure there is no interference or binding before riding the bike.



Clean Speed Engineering (CSE) LLC is not responsible for any issues resulting from the use of our products.

MADE IN THE USA