

## CSE Cable Guide Instructions

### Installing the Cable Guide

1. Remove the Cable Guide from the package and unscrew the two halves.
2. Place the two halves of the Cable Guide with the smaller hole around the post mount. At the same time capture the cables inside the larger hole.
3. Hold the cable guide in place with one hand and start the screws using the included hex wrench.
4. Before tightening the two screws position the Cable Guide so the cables run through it freely and don't contact the damper or handlebar mount.

Note: We recommend mounting the cable guide at the top of the post mount just under the plastic sleeve that holds the post. Four stroke models usually fit best at 3:00 (perpendicular to the frame) and two strokes at 7:00. These are just recommendations based on our experience you may find a better position for your application.

**ONCE POSITIONED MAKE SURE THE STEM PINCH BOLT ON THE TRIPLE CLAMPS CLEARS THE CABLE GUIDE.**

5. Tighten the screws with the included hex wrench.

**BE CAREFUL WHEN TIGHTENING THE CABLE GUIDE SCREWS - THESE ARE SMALL THREADS IN ALUMINUM - DO NOT OVERTIGHTEN.**

6. Once you have the Cable Guide mounted where you like it, be sure to put the bike on a stand and turn the bars from stop to stop to make sure there is no interference or binding before riding the bike.

### Determining Post (Tower) Diameter

Some post mounts are 1/2" diameter and some are 9/16". Before ordering a cable guide, measure your post mount using either a micrometer or caliper. If you don't have access to the tools to measure your post, open the Post Diameter pdf file linked on the web page and it will instruct you on how to measure it with out tools.



Clean Speed Engineering (CSE) LLC is not responsible for any issues resulting from the use of our products.

MADE IN THE USA